

Handset

Adjust the tilt of the screen

- **Indicator light**
 - flashing green: incoming call
 - flashing red: alarm



Socket for connecting headphones or a Hands-free / Loudspeaker unit

Alphabetic keypad

■ **Display and display keys**
Contains several lines and pages providing information on calls and the functions accessible via the 10 keys associated with the words on the screen.

- Diversion icon:** pressing the key next to this icon allows you to program or change the diversion function.
- Headset connected.**
- Appointment programmed.**
- Silent mode activated.**
- Telephone locked.**
- Display keys:** pressing a display key activates the function shown associated with it on the screen.

■ **Navigation**

- OK key:** used to validate your choices and options while programming or configuring.
- Left-right navigator:** used to move from one page to another.
- Up-down navigator:** used to scroll through the content of a page.
- Back/Exit key:** to return to previous menu (short press) or return to first screen (long press) ; during a conversation, provides access to welcome screens (Menu, Info, ...) and to return to the conversation icon screens.

■ **Welcome screens**

Menu page: contains all functions and applications accessible via the keys associated with the words on the screen.

Perso page: contains call line keys and programmable call keys.

Info page: contains information on the telephone and the status of its functions: name, telephone number, number of messages, activation of diversion function, appointment reminder, etc.

■ **Call display**

- Incoming call.**
- Call in progress or outgoing call.**
- Call on hold.**

If you get two calls at the same time, you can switch from one call to the other by pressing the display key associated with each call.

Left-right navigator: used to check calls.

OK key: used to answer the call checked.

■ **Function keys and programmable keys**

- Guide key:** used to obtain informations on functions of the "menu" page and to program key of the "perso" page.
- Messaging key to access various mail services**
If the key flashes, a new voice message or a new text message has been received.
- "Redial" key :** call back the last number dialed.
- Programmable key (F1 and F2 keys)**
Lit when the function associated with the key is activated.

■ **Audio keys**

- Hang-up key:** to terminate a call.
- Hands-free/Loudspeaker Key:** to make or answer a call without lifting the receiver.
 - lit in hands-free mode or headset mode (short press),
 - flashing in loudspeaker mode (long press).
- Intercom/Mute key:**
 - During a conversation: press this key so that your correspondent can no longer hear you.
 - Terminal idle: press this key to answer calls automatically without picking up the receiver.
- To adjust the loudspeaker or handset volume up or down.**

■ **Extension unit**

An extension unit can be fitted to your telephone. This provides additional keys which can be configured as function keys, line keys, call keys, etc.

To affix labels: push the holding strip of the unit backwards to you and lift it. Install the label under the keypad, in the housing designed for, and place the keypad back into position.

Customize your terminal Menu

The customization functions of the telephone are accessed from the **Menu** page.

Modifying your personal code Menu

reach the "menu" page

follow informations displayed on the screen

Lock / unlock your telephone Menu

reach the "menu" page

depending the displayed informations, enter your password or confirm

your telephone is locked/unlocked

Adjusting the audio functions Menu

reach the "menu" page

adjust ringing (melody, volume, mode,...) by following instructions displayed on the screen

Adjusting screen brightness IP Touch 4038 Menu

reach the "menu" page

increase or decrease the contrast

OR

adjust the contrast by consecutive presses

Using your telephone

Identify the terminal you are on

Info

The number of your telephone is displayed on the "Info" page.



Access the **Info** page using the navigator.

Making a call



lift the receiver

OR



hands free

OR



programmed line key

OR



dial directly the number for your call



To make an external call, dial the outside line access code before dialling your correspondent's number.

Receiving a call




lift the receiver

OR



hands free

OR



press the key next to the "incoming call" icon


Redialling



last number redial

Make a call-back request to a busy number

the number you are calling is busy



hang up

Voice message service

Consulting your voice mailbox

If the key flashes orange, a new voice message or new text message has been received.



follow informations displayed on the screen

press the key next to "consult voice or text message"

Divert your calls to another number

Divert your calls to another number



press the key associated with the type of diversion required (immediate, if busy, if no reply etc.)



dial the destination number



press the ok key if programming is not automatically recorded

Diverting calls to your voice mailbox



press the key associated with "divert to voice mailbox"



press the ok key if programming is not automatically recorded

When you return, cancel all diversions



press the key next to "cancel or deactivate the diversion"



if necessary, confirm cancellation of the diversion

Directory

Using call by name



enter the first letters of the name



confirm if the name of the person you are calling is not displayed



display the correspondent's identity



select the name from the displayed list



make the call

Program your call keys

Perso



OR



follow informations displayed on the screen

press a call key or a programmable key (f1 or f2), either directly or via the **i** key

Make calls via your programmed call keys

Perso



access the perso page using the navigator



find the correspondent you want to call from the programmed call keys




call the chosen correspondent

During a conversation

Sending DTMF signals

During a conversation you sometimes have to send DTMF signals, such as with a voice server, an automated attendant or a remotely consulted answering machine. The function is automatically cancelled when you hang up.



during a conversation



OR



to activate

Calling a second person during a conversation

During a conversation, to call a second person.



OR



dial

the first call is on hold

dial directly the number for your call

Transferring a call

During a conversation, to transfer the call to another number:



number to be called



Three-way conference

During a conversation, a second call is on hold.



three-way conference



cancel conference and return to first correspondent



hang up on all correspondent

Guarantee and clauses

This document describes the services available on telephones in the IP Touch range connected to an Alcatel OmniPCX Office or Alcatel OmniPCX Enterprise system .
Warning: never place your telephone in contact with water. To clean your telephone, you may however use a damp soft cloth. Never use solvents (trichlorethylene, acetone, etc.) which may damage the plastic parts of your telephone. Never spray it with cleaning products.
Earpiece may retain magnetic objects.

The wording is not contractual and may be subject to change. Some functions of your telephone are controlled by a software key and the configuration of the unit.

EC: We, Alcatel Business Systems, hereby declare that we assume the Alcatel IP Touch (4038 or 4068) product to be compliant with the essential requirements of Directive 1999/5/CE of the European Parliament and Council. A copy of the original of this declaration of compliance can be obtained from your installer.

IP Touch 4068

This apparatus makes use of a frequency spectrum, which use is not harmonized throughout the countries of the EC. The frequency spectrum may be shared with other applications and its operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device is designed and manufactured not to exceed the emission limits for exposure to radio frequency energy in SAR (Specific Absorption Rate) set by the concerned countries (Federal Communications Commission for the United-States).

Alcatel Business Systems, in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice. Copyright © Alcatel Business Systems. 2004. All rights reserved.



3GV19001BSAA010424